

Marine Kettle Combination Stove & Gas Grill

Trouble Shooting Guide

Problem	Possible Cause	Possible Solution
Burner will not light	No gas flow	Check fuel level, refill cylinder or replace canister
	Obstruction of gas flow	Visually check for obstructions / debris & clean inside of venturi tube & burner with a clean cloth
	Disconnected gas supply	Make sure canister is properly attached
Flare up	Grease and/or residue build-up	Clean internal components
	Excessive fat in meats	Trim fat from cuts of meat before grilling
	Excessive oils in marinades	Use non-oil based marinades
	Excessive cooking temperature	Reduce valve setting, leave lid open, or spray with water to cool
Yellow sooty flame	Obstruction of gas flow	Visually check for obstructions / debris & clean inside of venturi tube & burner with a clean cloth
Flame goes out	Valve/flame setting too low	Increase valve setting & relight
	Valve set to low, lid is closed or Opened to quickly	Increase valve setting & relight
	Empty fuel supply	Refill fuel tank or replace canister
	High or gusty winds	Rotate valve / venturi tube assembly to downwind side of grill. Increase temperature setting & relight
	Wind directly on grill surface	Use grill lid as windshield to block wind by attaching to windward side of grill (see page 4 of owners manual)
	Obstruction of gas flow	Visually check for obstructions / debris & clean inside of venturi tube & burner with a clean cloth

